





Do not operate with power supply connected.




AC220-240V | 50/60Hz | IP20 | Bioplastic | Adjustable

To mount the track adaptor into the track system, first check that the selector knob (A) is at OFF position and the adaptor lock **B** is disengaged.




When installing the adaptor into the track, ensure that it is orientated correctly.




Rotate adaptor lock **B** clockwise 90° to connect the adaptor to the neutral circuit.






Rotate selector knob (A) to the position of desired circuit.






Circuit 1: Rotate the knob ( 90° clockwise from the starting position OFF, to connect circuit 1.






Circuit 2: Rotate the knob (A) 90° anti-clockwise from the starting position OFF, to connect circuit 2.



Circuit 3: Rotate the knob (A) 180° clockwise from the starting position OFF, to connect circuit 3

## 5



## Warnings:

- 1. Make sure that the product is installed properly before connecting to electricity.
- 2. Do not cover the fitting.
- 3. Maintenance and installation should only be carried out by a professional electrician.
- 4. Consult qualified electrician should the installer be in any doubt.